



PSP 300xc Front Case Replacement

Replacement of PSP 300xc front case

Written By: Matt Newsom



INTRODUCTION

Make you PSP 3000c like new again by replacing your beat up front case with a shiny new one!



TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [Spudger](#) (1)



PARTS:

- [Sony PSP 3000 Front Case](#) (1)
- [Sony PSP 300xc Screw Set](#) (1)

Step 1 — Battery



- Press the button securing the battery door to the PSP 300xc, and lift the battery door off.
- Lift the battery out of the PSP.

Step 2 — Front Case



- Use a spudger or your fingernail to remove the warranty sticker stuck to the inside of the battery tray

Step 3




- Remove four Phillips screws from the back of the PSP.

Step 4



- Remove two Phillips screws from the top of the PSP.

Step 5



- Remove a single screw from the bottom edge of the PSP.

Step 6



- Insert a spudger between the front case and PSP, and slide the spudger along the perimeter of the front case to remove it.

To reassemble your device, follow these instructions in reverse order.

